



FOR INFORMATION ONLY
ASSEMBLY OF THE ROTOR
INNER SPACERS ARE USED TO SEPARATE THE PERMANENT MAGNETS